


X-125

Spare parts list





SPARE PARTS LIST

X-125

Pos	Description	Art.no.	Comment
1.	Fan, complete X125-14	22300145	pos 16-20
2.	Air piping assy	22300094	
3.	Solenoid valve 1"	499 S54045	2 pcs
4.	Diaphragm 1"	499 54400	
5.	Valve plate dia. 210mm	299 00017	2 pcs
6.	Air pipe	22300097	2 psc
7.	Filter lid	299 00015	2 pcs
8.	Double-acting cylinder	299 00014	2 pcs
9.	Filter	299 00013	2 pcs
10.	Excenter lock	399 14810	3 pcs
11.	Filter protection	299 00011	2 pcs
12.	Excenter lock	299 00039	4 pcs
13.	Wear protection	299 00020	
14.	Wear protection fastening	22300127	2 pcs
15.	Bottom housing section	299 00010	
16.	Hydraulic motor	399S40050	
17.	Fan top	22300011	
18.	Fan wheel for X125-14	299 00005	
19.	Sealing 8x4x2010mm	299 00006	
20.	Fan housing	299 00007	
21.	Hatch stay	22300165	
22.	El. cabling assy	22300133	with Harting connection
23.	Air connection 1"	22300096	
24.	Sealing strip 2440mm	299 00021	2 pcs
25.	Inlet gasket	299 00019	
26.	Inlet 5"	299 00018	
27.	Filter housing	299 00022	
28.	Sealing 25x10x1200mm	299 00012	2 pcs
29.	Clamp for rubber valve	299 00009	
30.	Rubber valve	299 00008	
31.	Control valve 5/2	299 00001	2 pcs
32.	El. cabling protection	22300088	
33.	Hosing assy	299 00024	